#### PLAY MODULE

#### Into the woods

Into the woods is a game which challenges children to sort the animals to bring them back to their homes. The rectangular wall game has a natural, modern frame made of birch plywood with a white painted front which compliments many environments.

Graphic colours Pantone no.





#### Play module | Into the woods

(EN 71

Article no.	Frame colour	Colour code	Size HxWxD	Mounting	Age	KG	
PP00703	White	RAL 9003	70x45x4,5cm	wallmount	2 - 8 years	5,8 KG	MDF, ABS, Beechwood, RVS, Birch Plywood




**III** All our products are inspected, tested **SGS** and certified by SGS and TÜV.

European standard EN 71 specifies safety requirements for toys. Compliance with the standard is legally required for all toys sold in the European Union. All our products only use FSC certified wood, so eco- and environment friendly!

CC Our products are conform with health, safety and environmental protection standards for products sold within the EU. IKC | HQ EUROPE Dronten | The Netherlands +31 (0)321 38 77 30 sales@ikcplay.com www.ikcplay.com IKC | HQ ASIA Shanghai | China +86 (0)573 82 58 61 83 sales.cn@ikcplay.com www.ikcplay.com.cn


### Playable on one side




### Playable on both sides














#### **TOOLS OVERVIEW**





Screws







#### 1. WALL MOUNTING | 2. FM FRAME MOUNT


S16

**Play Module** PM<sup>A</sup> PM<sup>B</sup> All the play modules needs to be mounted 40 cm above the ground. This is for the optimum play comfort.







#### **Required tools**




**2.1 Play Module with FM Frame** • PM<sup>B</sup> To put a playmodule on a FM frame, you should remove these slats.







**3.1 Play module** PM<sup>A</sup> • PM<sup>B</sup> To put a play module on a playsystem,


you should remove these slats.






#### **Required tools**







**Play module** PM<sup>A</sup> • PM<sup>B</sup> All the play modules needs to be mounted 40 cm above the ground. This is for the optimum play comfort.




#### 4.1 Install play module on play tower Required tools





# **5.1 Install FM Frame to play module** • PM<sup>B</sup> To put a playmodule on a FM frame, you should remove these slats.




## 5.2 Install play module with FM frame on play tower Required tools









#### 6.1 Install play module on fence Required tools




# **7.1 Install FM Frame to play module** ● PM<sup>B</sup> To put a playmodule on a FM frame, you should remove these slats.




## 7.2 Install play module with FM frame on fence Required tools



#### 8. FENCE





S19

S9